

Genesis Scanner Configuration Procedure

Note: When scanning the bar codes below be sure to place the barcode in front of the scanner and press the button on top of the scanner.

1. Power-up the scanner.
2. Scan the *enter/exit configuration mode* bar code (3 beeps).

Enter Configuration Mode



3. Scan the bar code for the Disable feature (1 beep).

Disable CR Suffix.



4. Scan the bar code for the Disable feature (1 beep).

Disable LF Suffix.



5. Scan the *enter/exit configuration mode* bar code (3 beeps) to save the new configuration.

Exit Configuration Mode

